pin 9 is pos side of trip sensing ckt.

pin 10 is neg side.

pin 9 is RED lite ind.

pin 12 is neg side.

pin 11 is GRN lite ind

pin 4 is pos side of close/open switch circuit.

pin 8 is neg side.

BREAKER SIMULATOR